

# MCREESPRECISION Rear Stock Pack

Your “Rear Stock Pack” (RSP) is universal, can be used by right or left handed shooters. A short description for how to adjust and change from Right to Left is below.

This piece of kit is made 100% American.

Thank You for purchasing this product and supporting our effort to keep jobs in the USA.

Proper location: See pic 1. The best fit/function position should have the entire cheek piece covered, front to rear. Only install the RSP after you have fully adjusted the rear assembly of your stock. Lay the RSP over the cheek pcs and gauge how much pad strap you will need to assure proper alignment with the cheek pcs. (See pic 2) Insert a flat item or even an ink pen, between the hook and loop. Then pull the pad strap from its slot. Re-insert the pad strap to the estimated depth that will give you the proper cheek pc alignment. You will have to do this with both ends of the pad strap. We recommend that you try to get an even amount of strap inserted to both locking areas. Once you have completed this operation, remove the item you have used for inserting and attach the unit to the rear of the stock.

Right/Left Hand Change: See pic 2. Insert a flat item or even an ink pen, between the hook and loop. Then pull the pad strap from its slot. Re-insert the pad strap in the other end, using the flat item or ink pen to keep the hook/lop from setting. Once you have completed this operation, remove the item you have used for inserting and attach the unit to the rear of the stock. You are basically repeating the steps for Proper Location, just doing it on the other end of the RSP.

RSP-U weighs 5 ounces



(1)



(2)

Designed by: McRee's Multi Services, 36159 Hwy 21, Lesterville, MO, 63654 Phone (573) 637 – 2000  
Fax (573) 637 – 2004 E-Mail: [1000yards@mcreesprecision.net](mailto:1000yards@mcreesprecision.net)

**Made in the USA, produced by Tactical Tailor for MCREESPRESION**